



FOR DETAILED SPECIFICATIONS, SEE WWW.PHANTOMSSCREENS.COM

PHANTOM SCREEN DETAIL (CROSS SECTION LOOKING DOWN) FULL SCALE

MOULDING AT BOTTOM OF CABINET FACES ABOVE TOE SPACE DETAIL FULL SCALE

BUNK TRIM DETAIL FULL SCALE

SHOWER DOOR KNOB LATCH FULL SCALE

NOTE: THIS DRAWING IS INTENDED TO BE USED AS A REFERENCE ONLY. IT IS NOT TO BE USED AS A CONSTRUCTION DOCUMENT. THE CONTRACTOR SHALL BE RESPONSIBLE FOR VERIFYING ALL DIMENSIONS AND CONDITIONS BEFORE CONSTRUCTION. ANY DISCREPANCIES SHALL BE REPORTED TO THE ARCHITECT IMMEDIATELY. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING CONDITIONS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR MAINTAINING ACCESS TO ALL SERVICES. THE CONTRACTOR SHALL BE RESPONSIBLE FOR CLEANING UP AFTER CONSTRUCTION. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING CONDITIONS. THE CONTRACTOR SHALL BE RESPONSIBLE FOR MAINTAINING ACCESS TO ALL SERVICES. THE CONTRACTOR SHALL BE RESPONSIBLE FOR CLEANING UP AFTER CONSTRUCTION.